


HOW TO MEASURE

p a n e l g l i d e





flair
21

Panel glide tracks are available up to 228" long with flat fabric panels up to 112" tall that attach using Velcro®. The average panel size is 24" to 36"; the width of your panel is also the width of your stack back. Panel glides may be wall or ceiling mount with a combination of 2 to 18 panels, in one-way or split draw and baton or cord drawn.

INSIDE MOUNT

- For the **length**, use the smallest measurement from inside the top casing of the window to inside the bottom casing or the floor.
- To find the **width**, measure inside the window casing from left to right.
- **flair21 will take $\frac{3}{8}$ " deduction for width and length** to allow for clearance.



OUTSIDE MOUNT

- Measure the **width** and **length** you wish to cover (NOTE: This is typically 2" to 4" from the outside edge of the window—from the top of the headrail, to the bottom of the fabric panel).
- **flair21 does NOT make any deductions** or additions.

DESIGNER'S TIP

- For the **length**, it is good to **measure from 4" to 6" above the casing** to just above the floor. Hanging your treatment higher will give your room the illusion of taller ceilings and bigger windows.
- You can also create the illusion of larger windows by **allowing the panels to stack next to the window** instead of covering it. The track should **extend one panel width beyond the window** to allow for stack-back.